



On the left navigation bar, Click Serial Port > Connection > Port Title #

Vetwork	Serial port connection				
	/ serial / serial_connect				
Serial port	Peer: All peers 🛩				
Configuration	Slave name:	Port title:	Search		
Connection					
Ilustering	Port access menu connect	ion			
Power controller	Port access menu connection				
Peripherals	Individual port connection				
	Status Port#	Title	# of User	Comments	
Custom menu	1	Port Title #1	0	< Not used >	
System status & log	2	Port Title #2	0	< Not used >	
System administration	3 4	Port Title #3 Port Title #4	0	< Not used > < Not used >	
System statistics	5	Port Title #5	ő	< Not used >	
	6	Port Title #6	ō	< Not used >	
Activate Passport Locator LED	7 8	Port Title #7 Port Title #8	0	< Not used > < Not used >	
Apply Changes	9	Port Title #9	ő	< Not used >	
Login as a different user	10	Port Title #10	0	< Not used >	
Logout	11 12	Port Title #11 Port Title #12	0	< Not used > < Not used >	
Reboot	12	Port Title #13	0	< Not used >	
	14	Port Title #14	0	< Not used >	
	15	Port Title #15 Port Title #16	0	< Not used > < Not used >	
	10	Port Title #17	0	< Not used >	
	18	Port Title #18	0	< Not used >	
	19	Port Title #19	0	< Not used >	
	20 21	Port Title #20 Port Title #21	0	< Not used > < Not used >	
	22	Port Title #22	0	< Not used >	
		Port Title #24 Port Title #25	0	< Not used >	
	26	Port Title #26	ō	< Not used >	
		Port Title #27			
	30	Port Title #30	ő	< Not used >	
	31	Port Title #31	0	< Not used >	
	32	Port Title #32	0	< Not used >	
	22 23 24 25 26 27 28 27 28 29	Port Title #22 Port Title #23 Port Title #24 Port Title #25 Port Title #26 Port Title #27 Port Title #28 Port Title #28 Port Title #29	0 0 0 0 0 0 0	<pre>&lt; Not used &gt; &lt; Not used &gt;</pre>	

address bar and log in. Use the navigation bar on the left to alter your configuration.

Logn as a different user Logout	Use Manual DNS:	Enable M
Reboot	Primary DNS:	10.9.8.60
	Secondary DNS (optional):	10.10.8.62
	Source based routing:	Disable w
	Save to Rash Save & apply	Cancel

Below is a list of available adapters and part numbers.

Connection	Adapters (in quantities of 8)	Order #	Application
	DB-9M Modem adapter	76000702	DCE devices such as modems with DB9 female ports
	DB-9F Console adapter	76000671	Bay Accelar, Nortel and other DB-9 DTE
	DB-25F Console adapter	76000673	DTE devices with DB-25 male ports
	DB-25M Modem adapter	76000670	DCE devices such as modems
	DB-25M Console adapter	76000672	Sun SPARC and other DTE devices with DB-25 female ports

© Digi International, Inc., 2011

Digi, Digi International, Digi Passport and the Digi logo are trademarks or registered trademarks of Digi International, Inc., in the United States and other countries worldwide. All other trademarks are property of their respective owners.